



YELLOW WIRES ARE NOT POLARITY SENSITIVE.
CONNECT ONE WIRE TO NEGATIVE GROUND OF TOW VEHICLE.
CONNECT OTHER WIRE TO POSITIVE BACK UP LIGHT WIRE OF
TOW VEHICLE.

WHEN VEHICLE IS SHIFTED INTO REVERSE, SOLENOID WILL ACTIVATE
AND PREVENT BRAKE FLUID FROM GOING TO TRAILER BRAKE SYSTEM
ALLOWING TRAILER TO BE BACKED UP.

